Charging & Operation



The tracker should be charged before each use and periods of storage. Only use the original USB cable provided with the tracker to charge. A charging plug rated at 5V/2A is recommended to charge the tracker.

Charging can take up to 9 hours but must not exceed 15 hours. \land Never leave the device unattended while charging.

Status LEDs

GSM LED (Green) Flashing - Signal Established

GPS LED (Blue) Battery LED (Red) Solid - Device is Flashing - Signal Established Charging

Solid - Device

Off - Power off

Solid - Device Off - Power off Searching for signal Searching for signal or fully charged

Off - Power off or in sleep mode or in sleep mode



Fitting the device

The easiest way to fit the 104 is to attach it to the metal surface underneath the vehicle that you wish to track. The tracker features a magnetic base for easy mounting. While installing, always make sure the surface you are attaching to is clean, flat and away from any sources of heat. Care should be taken to make sure the tracker is not positioned in



an area where the tracker could be knocked off or damaged by moving parts.

The waterproof pouch provided with the tracker should always be used. The pouch should be checked before each use to ensure it is closed tightly and is not damaged in anyway. If damaged, the pouch should be replaced immediately to avoid invalidating the trackers warranty.

If you have just activated the tracker it can take up to 10 minutes to establish an initial GPS fix. A short journey will allow the tracker to establish a GPS satellite fix quicker.

Accessing your account

To access your account please visit: WWW.GPSLIVE.CO.UK or get our free to download app GPSLive on Google Play or Apple App Store.



If you have purchased this device with subscription, it will have already been added to your account. You'll receive your login details via email if you're a new user.

How do I manage my subscription?

Visit WWW.GPSLIVE.CO.UK, log in and follow the instructions below:



IF YOUR SUBSCRIPTION RUNS OUT, YOUR VEHICLE WILL NOT BE PROTECTED AGAINST THEFT AND TRACKING WILL BE DISABLED DURING THIS PERIOD.

ATTENTION

- \triangle Do not drop or impact this device.
- A Keep this device away from water, fire, humidity or hot environments.
- \triangle Do not attempt to disassemble, modify or repair this device by yourself.
- \triangle Do not use a damaged power adapter or USB cable to charge this device.
- \triangle If the product appears to be bulging or shows other undesirable phenomena, stop using the product immediately and contact us or your dealer.
- \triangle This product is not suitable for those lacking relevant knowledge and experience.
- \triangle Use under the supervision and guidance of professionals.
- \triangle Charge this device once every three months to avoid shortening its battery life.
- \triangle Use the recommended power adapter to charge this device.
- \triangle Power adapter is not provided by Rewire Security.